

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energoefektivitātes

Table with columns for technical specifications: PF (FABER), IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV. Rows include model details (S, M), energy efficiency classes (AEC, EEC, FDE, FDEChood, LE, LEC, GFE, GFEC, Qmin, Qmax, Qboost, SPemin, SPemax, SPEboost, PO, Ps), airflow metrics (Qmin, Qmax, Qboost), power consumption (Pg, Ps), and performance metrics (f, EElhood, Qbep, Pbeq, Qmax, Wbep, Wl, Emiddle, Lwa). Each row contains values for various units like kWh/a, m3/h, dBA, Pa, W, lux, and dBA.

